

Brillia Series


RAX21 SQB-X Series

Under Cabinet Model: RAX2130SQB-1 (30") / RAX2130SQB-2 (30")

RAX2136SQB-1 (30") / RAX2136SQB-2 (36") RAX2142SQB-1 (42") / RAX2142SQB-2 (42")

Wall Mount Model: RAX2130SQB-WM-1 (30") / RAX2130SQB-WM-2 (30")

RAX2136SQB-WM-1 (36") / RAX2136SQB-WM-2 (36") RAX2142SQB-WM-1 (42") / RAX2142SQB-WM-2 (42")



INSTALLATION INSTRUCTIONS AND OPERATION MANUAL

IMPORTANT READ THIS FIRST

READ BEFORE INSTALLATION

- 1. Carefully check all contents of package(s).
- 2. Thoroughly inspect the unit for any shipping damages, cosmetic damages or defects.
- Have a certified contractor/electrician test the unit before installation.

IF THERE IS ANY PROBLEMS:

- 1. <u>DO NOT INSTALL THE UNIT AND KEEP ALL ORIGINAL PACKAGING MATERIALS.</u>
- 2. Have your invoice as proof of purchase and product serial number ready.
- 3. Contact your merchant for product replacement due to shipping damages, cosmetic damages or defects.
- 4. For all other issues, email customer.service@koberangehoods.com

NO RETURN, NO REFUND, NO EXCHANGE IF:

- 1. PRODUCT HAS BEEN INSTALLED
- 2. KNOCK-OUT HOLES HAVE BEEN PUNCTURED
- 3. MISSING ORIGINAL PACKAGING MATERIAL AND/OR PARTS

[ENGLISH]

- READ AND SAVE THESE INSTRUCTIONS -

CONTENTS

IMPORTANT SAFETY INSTRUCTIONS	1
COMPONENTS OF PACKAGE	3
INSTALLATION	5
OPERATING INSTRUCTIONS	10
MAINTENANCE	11
SPECIFICATIONS	12
MEASUREMENTS & DIAGRAMS	13
PARTS LIST	14
CIRCUIT DIAGRAM	16
TROUBLE SHOOTING	17
WARRANTY	18
WARRANTY INFORMATION FORM	20

- READ ALL INSTRUCTIONS CAREFULLY BEFORE STARTING -

ALL WIRING MUST BE DONE BY A PROFESSIONAL AND IN ACCORDANCE WITH NATIONAL AND LOCAL ELECTRICAL CODES



IMPORTANT SAFETY INSTRUCTIONS

- PLEASE READ THIS SECTION CAREFULLY BEFORE INSTALLATION -

WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR PERSONAL INJURY, OBSERVE THE FOLLOWING:

- 1. Installation and electrical wiring must be done by qualified professionals and in accordance with all applicable codes and standards, including fire-rated construction.
- 2. When cutting or drilling into wall or ceiling, be careful not to damage electrical wiring or other hidden utilities.
- 3. Ducted fans must be vented to the outside.
 - a. Before servicing or cleaning unit, open the light panel and SWITCH POWER OFF AT SERVICE PANEL.
 - b. Clean all grease laden surfaces frequently. To reduce the risk of fire and to disperse air properly, make sure to vent air outside. DO NOT vent exhaust air into wall spaces, attics, crawl spaces or garages.

NOTE

- This warrant is void without an authorized agent's receipt or if unit is damaged due to misuse, poor installation, improper use, mistreatment, negligence or any other circumstances beyond the control of KOBE authorized agents. Any repair carried out without the supervision of KOBE authorized agents automatically void the warranty.
- KOBE will not be held responsible for any damages to personal property or real estate or any bodily injuries whether caused directly or indirectly by the range hood.

WARNING: TO REDUCE THE RISK OF PERSONAL INJURY IN THE EVENT OF A RANGE TOP GREASE FIRE:

- 1. Keep all fan, baffle/spacer/filter/oil tunnel/oil container and grease-laden surfaces clean. Grease should not be allowed to accumulate on fan, baffle/spacer/filter/oil tunnel/oil container.
- 2. Always turn hood ON when cooking.
- 3. Use high setting on cooking range ONLY when necessary.
- 4. Do not leave cooking range unattended when cooking.
- 5. Always use cookware and utensils appropriate for the type and amount of food prepared.
- 6. Use this unit only in the manner intended by the manufacturer.
- 7. Before servicing, switch power off at service panel and lock service panel (if possible) to prevent power from switching on accidentally.
- 8. Clean ventilating fan frequently.

What to Do in the Event of a Range Top Grease Fire

- SMOTHER FLAMES with a tight fitting lid, cookie sheet, or metal tray, and then turn off the burner. KEEP FLAMMABLE OR COMBUSTIBLE MATERIAL AWAY FROM FLAMES. If the flames do not go out immediately, EVACUATE THE AREA AND CALL THE FIRE DEPARTMENT or 911.
- 2. NEVER PICK UP A BURNING PAN You May Get Burned.
- 3. DO NOT USE WATER, including wet dishcloths or towels a steam blast will result.
- 4. Use an extinguisher ONLY if:
 - a. You have a Class A, B, C extinguish and know how to operate it.
 - b. The fire is small and contained in the area where it started.
 - c. The fire department has been called.
 - d. You can fight the fire with your back to an exit.

What TO Do If You Smell Gas

- 1. Extinguish any open flame.
- 2. Do not try to turn on the lights or any type of appliance.
- 3. Open all doors and windows to disperse the gas. If you still smell gas, call the Gas Company and Fire Department right away.

A CAUTION

- 1. For general ventilation use only. Do not use to exhaust hazardous or explosive materials and vapors.
- 2. To reduce the risk of fire, use only metal ductwork. Sufficient air is needed for proper combustion and exhausting of gases through the flue (chimney) to prevent back drafting.
- 3. Follow the heating equipment manufacturer's guideline and safety standards such as those published by the National Fire Protection Association (NFPA), and the American Society for Heating, Refrigeration and Air Conditioning Engineers (ASHRAE), and code authorities.
- 4. Activating any switch may cause ignition or an explosion.
- 5. Due to the size and weight of this hood, installation by 2 persons is recommended.

A WARNING




ELECTRICAL SHOCH HAZARD – Can result in serious injury or death. Disconnected appliance from electric power before servicing. If equipped, the fluorescent light bulb contains small amount of mercury, which must be recycled or disposed of according to Local, State, and Federal Codes.

COMPONENTS OF PACKAGE

(Must keep all materials for returns or refunds)

For Under Cabinet Application

Model No.: RAX2130SQB-1 (30") / RAX2130SQB-2 (30") RAX2136SQB-1 (36") / RAX2136SQB-2 (36") RAX2142SQB-1 (42") / RAX2142SQB-2 (42")




 FOR MORE INFORMATION, PLEASE VISIT OUR WEBSITE <u>www.koberangehoods.com</u> OR CONTACT KOBE RANGE HOODS <u>customer.service@koberangehoods.com</u>.

(Must keep all materials for returns or refunds)

For Wall Mount Application

Model No.: RAX2130SQB-WM-1 (30") / RAX2130SQB-WM-2 (30") RAX2136SQB-WM-1 (36") / RAX2136SQB-WM-2 (36") RAX2142SQB-WM-1 (42") / RAX2142SQB-WM-2 (42")



 FOR MORE INFORMATION, PLEASE VISIT OUR WEBSITE <u>www.koberangehoods.com</u> OR CONTACT KOBE RANGE HOODS customer.service@koberangehoods.com.


INSTALLATION

PLEASE READ ENTIRE INSTRUCTIONS BEFORE PROCEEDING


Calculation before Installation

To calculate installation, please refer to TABLE 1 and TABLE 2. (All calculations in inches).

- FOR UNDER THE CABINET -



- FOR WALL MOUNT (WITH OPTIONAL DUCT COVER) -



A SAFETY WARNING

- HOOD MAY HAVE SHARP EDGES; PLEASE WEAR PROTECTIVE GLOVES IF REMOVING ANY PARTS FOR INSTALLING, CLEANING, OR SERVICING.
- BE CAREFUL WHEN USING ELECTRICAL SCREWDRIVER, DAMAGE TO THE HOOD MAY OCCUR. USING HAND TOOLS IS RECOMMENDED. DO NOT OVER TIGHTEN SCREWS.
- MAKE SURE TO PREVENT ANY DEBRIS FROM ENTERING THE VENT OPENING TO AVOID DAMAGE OR MALFUCTION.

UNDER CABINET INSTALLATION

Before Installation

- 1. Read any provided document(s).
- 2. Test the range hood by temporarily connecting it to an outlet and turning ON the fan and lights.
- 3. If you run into any problems, contact KOBE Range Hoods.

Venting Requirements

- 4. The range hood has top 6" round exhaust (default).
- 5. Decided the location of the venting pipe from the hood to the outside. A straight, short vent run will allow the hood to perform more efficiently. Try to avoid elbows, transitions, and long run as much as possible as this may reduce the performance of the hood. Make sure that the duct work leads to the outside.
- 6. It is recommended to use metal/aluminum duct/pipe with a uniform size (ex. 6" round pipe from range hood to the outside).
- 7. If an elbow is necessary, a minimum of 12" straight run is necessary before the elbow.

Clearance

- 8. Clearance is the distance between the cooktop and the bottom of the range hood. The recommended minimum clearance for this model is 26" and the maximum clearance is 30".
- 9. It is important to install the hood at the recommended clearance. Installing too low could result in damage and/or fire hazard while installing too high may result in reduced performance and efficiently.

Hood Installation

- 10. Make sure the cabinet has full access opening for the hood as shown on Figure 1.
- 11. Using reference on TABLE 1 and measurements on page 13 to mark the leveling point for hood-mounting bracket inside the cabinet.
- 12. Secure two 4*35 screws (provided) inside the cabinet leaving 1/8" away from the cabinet as shown on Figure 2.
- 13. Align hood-mounting bracket to the mounting screws inside the cabinet and hook the hood into place. Secure and tighten the mounting screws. (Figure 2).

Ductwork

- 14. Put the two flappers on 6" round exhaust vent adapter. NOTE: striped side of the flapper is facing out.
- 15. Attached the rubber plate to the bottom of 6" round exhaust vent adapter then attached to the exhaust opening and use six 4*6 screws to secure it.
- 16. Use steel pipe to connect the 6" round exhaust on the hood to the ductwork above. Use duct tape to make all joints secure and air tight. Refer to Figure 3.




Figure 1




Figure 2

Electrical Wire

- 17. Connected the range hood to an outlet.
- 18. If hardware is desired, cut off the plug and connect three wires (black, white, and green) to the outlet wires and cap with wire connectors. Connect the wires according to color (ex. black to black).

Steel Pipe CABINET Duct Tape 6" Round Plastic Collar

Figure 3

CEILING

Finish

- 19. Remove any protective film from the hood, if any.
- 20. Before using, make sure that any accessories such as baffle filters are properly installed where applicable.
- 21. Test the range hood to see if it is working properly.

A THIS RANGE HOOD MUST BE PROPERLY GROUNDED. MAKE SURE THIS IS DONE BY QUALIFIED ELECTRICIAN IN ACCORDANCE WITH ALL APPLICABLE NATIONAL AND LOCAL ELECTRICAL CODES. BEFORE CONNECTING WIRES, SWITCH POWER OFF AT SERVICE PANEL AND LOCK SERVICE PANEL TO PREVENT POWER FROM BEING SWITCHED ON ACCIDENTALLY.

WALL MOUNT INSTALLATION

Before Installation

- 1. Read any provided document(s).
- 2. Test the range hood by temporarily connecting it to an outlet and turning ON the fan and lights.
- 3. If you run into any problems, contact KOBE Range Hoods.

Venting Requirements

- 4. The range hood has top 6" round exhaust (default).
- 5. Decided the location of the venting pipe from the hood to the outside. A straight, short vent run will allow the hood to perform more efficiently. Try to avoid elbows, transitions, and long run as much as possible as this may reduce the performance of the hood. Make sure that the duct work leads to the outside.
- 6. It is recommended to use metal/aluminum duct/pipe with a uniform size (ex. 6" round pipe from range hood to the outside).
- 7. If an elbow is necessary, a minimum of 12" straight run is necessary before the elbow.

Clearance

- 8. Clearance is the distance between the cooktop and the bottom of the range hood. The recommended minimum clearance for this model is 26" and the maximum clearance is 30"
- It is important to install the hood at the recommended clearance. Installing too low could result in damage and/or fire hazard while installing too high may result in reduced performance and efficiently.

Hood Installation

- 10. Prepare back wall frame with cross framing lumber for secure installation if necessary. Using references on TABLE 2 and measurements on page 13 to decide the level of the lumber.
- 11. Mark the leveling point of the hood. Position two 4*35 screws on the wall, leaving 1/8" away from the wall as shown in Figure 2.
- 12. Align hood-mounting bracket to the two screws on the wall and hook the hood into place. Tighten screws to secure hood to the wall.

Ductwork

- 13. Put the two flappers on 6" round exhaust vent adapter. NOTE: Striped side of the flapper is facing out.
- 14. Attached the rubber plate to the bottom of 6" round exhaust vent adapter then attached to the exhaust opening and use six 4*16 screws to secure it.
- 15. Use steel pipe to connect the 6" round exhaust on the hood to the ductwork above. Use duct tape to make all joints secure and air tight.




Figure 1



Figure 2

Duct Cover Installation

- 16. Use reference E from TABLE 2 and measurements on page 13 to mark the position of the duct cover-mounting bracket.
- 17. Secure the duct cover-mounting bracket to the wall with two 4*35 screws. Make sure all screws are tightened. Refer to Figure 3. NOTE: Inner duct cover will cover the duct cover-mounting bracket.
- Put the entire duct cover onto the hood and slide the inner duct cover until it reaches to the duct cover-mounting bracket.
- 19. Secure inner duct cover with two 4*8 screws to the duct cover-mounting bracket. Shown in Figure 4.



- 20. Connect the range hood to an outlet.
- 21. If hardware is desired, cut off the plug and connect three wires (black, white, and green) to the outlet wires and cap with wire connectors. Connect the wires according to color (ex. black to black).

Finish

- 22. Remove any protective film from the hood, if any.
- 23. Before using, make sure that any accessories such as baffle filters are properly installed where applicable.
- 24. Test the range hood to see if it is working properly.




Figure 3





Figure 4

THIS RANGE HOOD MUST BE PROPERLY GROUNDED. MAKE SURE THIS IS DONE BY QUALIFIED ELECTRICIAN IN ACCORDANCE WITH ALL APPLICABLE NATIONAL AND LOCAL ELECTRICAL CODES. BEFORE CONNECTING WIRES, SWITCH POWER OFF AT SERVICE PANEL AND LOCK SERVICE PANEL TO PREVENT POWER FROM BEING SWITCHED ON ACCIDENTALLY.

OPERATING INSTRUCTIONS

3-Speed Mechanical Push Button



NOTE: For best results, turn fan on prior to any preparation or cooking and keep fans running while cooking. Adjust speed as needed.

To operate the fan function

- Press button to choose from speed
 - Q = QuietMode™ speed
 - L = Low speed
 - H = High speed
- Press "OFF" to turn fan off

To operate the light function

Press the Light Control to turn lights on and off

MAINTENANCE

For optimal performance, clean the range hood surface and filters regularly.

To Clean Hood Surface

CAUTION: NEVER USE ABRASIVE CLEANERS, PADS, OR CLOTHS.

***Regular care will help preserve its fine appearance.

- 1. Use only mild soap or detergent solutions. Dry surfaces using soft cloth.
- If hood looks smudged (stainless steel hood), use a stainless steel cleaner to clean the surface of the hood. Avoid getting cleaning solution onto or into the control panel. Follow directions of the stainless steel cleaner. Caution: Do not leave on too long as this may cause damage to hood finish. Use soft towel to dry the hood.
- 3. DO NOT allow deposits to accumulate or remain on the hood.
- 4. DO NOT use ordinary steel wool or steel brushes. Small bits of steel may adhere to the surface and cause rusting.
- 5. DO NOT allow salt solutions, disinfectants, bleaches, or cleaning compounds to remain in contact with stainless steel for extended periods. Many of these compounds contain chemicals, which may be harmful to the hood. Rinse with water after exposure and wipe dry with a clean lint free cloth.

For Baffle Filter models only: to Clean Baffle Filters / Oil Tunnel

CAUTION: DRAIN OIL FROM BAFFLE FILTERS, SPACERS & OIL TUNNEL REGULARLY TO PREVENT OVERFLOW.

- 1. Remove all the baffle filters, spacers and oil tunnel. NOTE: Not all models have spacers and oil tunnel.
- 2. Using a sponge, wash with warm soapy water. Dry completely before returning into place. **CAUTION: SHARP EDGES**

(NOTE: Baffle Filters are top rack dishwasher safe)

SPECIFICATIONS

MODEL / SIZE		Under Cabinet Model N RAX2130SQB-1 (36 RAX2136SQB-1 (42 RAX2142SQB-1 (42 RAX2130SQB-2 (36 RAX2136SQB-2 (42 RAX2142SQB-2 (42	7") RAX2 S") RAX2 P") RAX2 P") RAX2 S") RAX2	nt Model No. 130SQB-WM-1 136SQB-WM-1 142SQB-WM-1 130SQB-WM-2 136SQB-WM-2 142SQB-WM-2	(36") (42") (30") (36")
COLOR		Commercial Grade Sta	inless Steel		
CONSUMPTION / AMI	PERE	126W / 1.41A			
VOLTAGE / Hz		110V / 60Hz			
NUMBER OF BLOWE	RS	1			
DESIGN		Seamless with Satin Fi	nish		
BLOWER TYPE		Single Horizontal Squir	rel Cage		
EXHAUST		Top 6" Round			
CONTROL		Mechanical Push Butto	n		
LIGHT		3-watt LED Light x 2			
HOOD DIMENSION (W x D x H)		RAX2130SQB-1 / RAX RAX2136SQB-1 / RAX RAX2142SQB-1 / RAX	2136SQB-2	29-3/4" x 20" x 35-3/4" x 20" x 41-3/4" x 20" x	: 12-3/16"
		RAX2130SQB-WM-1 / RAX2136SQB-WM-1 / RAX2142SQB-WM-1 /	RAX2136SQB-WN	I-2 35-3/4" x 20"	x (23-5/8"~42-1/2"
OPTIONAL ACCESSO (W x D x H)	ORIES	 30" Stainless Stee Model: SSP30 (30" 36" Stainless Stee Model: SSP36 (36" 	x 32" x 1/10") el Back Panel		
HOOD WEIGHT	RAX21365 RAX21425 RAX21305	SQB-1 / RAX2130SQB-2(SQB-1 / RAX2136SQB-2 SQB-1 / RAX2142SQB-2 SQB-WM-1 / RAX2130SQ	(36") (42") QB-WM-2 (30")	Net 30.0 lbs 33.0 lbs 35.0 lbs 40.0 lbs	Gross 37.0 lbs 41.0 lbs 44.0 lbs
		SQB-WM-1 / RAX2136S0 SQB-WM-1 / RAX2142S0		44.0 lbs 46.0 lbs	53.0 lbs 56.0 lbs
SPEED Air Capacity (cfm)		QuietMode™ 320	<u>Lo</u> 50	0	<u>High</u> 700

^{*}One sone is equivalent to the sound of a refrigerator at 40 decibels.

Decibel

59

75

67


^{**}Specifications subject to change without notice.

MEASUREMENTS & DIAGRAMS

- ***All inch measurements are converted from millimeters. Inch measurements are estimated.
- ***All measurements in () are millimeters.


- FOR UNDER THE CABINET -

MODEL NO.: RAX2130SQB-1 (30") / RAX2136SQB-1 (36") / RAX2142SQB-1 (42") RAX2130SQB-2 (30") / RAX2136SQB-2 (36") / RAX2142SQB-2 (42")



- FOR WALL MOUNT -

MODEL NO.: RAX2130SQB-WM-1 (30") / RAX2136SQB-WM-1 (36") / RAX2142SQB-WM-1 (42") RAX2130SQB-WM-2 (30") / RAX2136SQB-WM-2 (36") / RAX2142SQB-WM-2 (42")




PARTS LIST

MODEL NO.: RAX2130SQB-1 (30") / RAX2130SQB-2 (30")


RAX2136SQB-1 (36") / RAX2136SQB-2 (36") RAX2142SQB-1 (42") / RAX2142SQB-2 (42")

No.	Description	Model No.	Part No.
01	6" Round Exhaust Adapter		02-028
02	Hood-Mounting Bracket		02-029
03	Capacitor		02-004
04	LED Light		02-005
05	Control Switch		02-006
06	Blower System		YYC-148-3
07	Baffle Filter		02-026
08	LED Light Driver		02-001



MODEL NO.: RAX2130SQB-WM-1 (30") / RAX2130SQB-WM-2 (30") RAX2136SQB-WM-1 (36") / RAX2136SQB-WM-2 (36") RAX2142SQB-WM-1 (42") / RAX2142SQB-WM-2 (36")

No.	Description	Model No.	Part No.
01	Duct Cover-Mounting Bracket		02-039
02	Duct Cover		RAX21DC-2
03	6" Round Exhaust Adapter		02-028
04	Hood-Mounting Bracket		02-029
05	Capacitor		02-004
06	LED Light		02-005
07	Control Switch		02-006
08	Blower System		YYC-148-3
09	Baffle Filter		02-026
10	LED Light Driver		02-001




CIRCUIT DIAGRAM

MODEL NO.:

RAX2130SQB-1 (30") / RAX2136SQB-1 (36") / RAX2142SQB-1 (42") RAX2130SQB-2 (30") / RAX2136SQB-2 (36") / RAX2142SQB-2 (42")

RAX2130SQB-WM-1 (30") / RAX2136SQB-WM-1 (36") / RAX2142SQB-WM-1 (42") RAX2130SQB-WM-2 (30") / RAX2136SQB-WM-2 (36") / RAX2142SQB-WM-2 (42")



TROUBLE SHOOTING

Issue	Possible Cause	Solution
After	The power is not on.	Make sure the circuit breaker and
installation,		the unit's power is ON. Use a
both motors		voltage meter to check the power
and lights are		supply.
not working.	The wire connection is not secure.	Check and tighten wire connection.
	The control panel is defective.	Replace the control panel.
Lights are	The motor(s) is defective.	Replace the motor.
working, but	The capacitor(s) is defective.	Replace capacitor(s).
motor(s) is not.	The control panel is defective.	Replace the control panel.
The range	The blower system is not secure.	Tighten the turbine impeller /
hood is		squirrel cage and air chamber.
vibrating.	The turbine impeller / squirrel cage is	Replace the turbine impeller /
	not balanced.	squirrel cage.
	Hood is not secured in place.	Check the installation of hood,
		tighten the mounting bracket.
The motor is	LED light fixture(s) is defective.	Replace LED light fixture(s).
working, but	The light wiring(s) is loose.	Check wire continuity from Control
the lights are		Panel to LED Driver to LED light
not working.		fixture(s).
	The control panel or LED light driver is	Replace the control panel or LED
	defective.	light driver.
The range	The range hood is installed outside of	Adjust the clearance between the
hood is not	the manufacturer recommended	range hood and cook top to 26" to
venting out	clearance.	30". For island range hood, the
correctly.		clearance between the range hood
		and cook top is 30" to 36".
	There is no make-up air inside the	Open the window to enhance the
	house.	performance of the range hood by
		creating a sufficient make-up air.
	Obstacle blocking the pipe work	Remove all obstacles from the duct work.
	The pipe size is smaller than the	Change the ducting according to
	suggested pipe size.	the manufacturer suggestion.
Cold air is	The pipe connection is not properly	Check the pipe installation.
coming into	sealed.	
the home.	The damper is not properly installed or	Check the damper installation.
	is missing from the installation	
	The damper is not installed	Installing the damper will help
		eliminate air backflow.

WARRANTY CERTIFICATE

In order to obtain warranty service, you must provide proof of original purchase from a KOBE authorized dealer. Please keep a copy of your original invoice as proof of purchase.

TWO-YEAR LIMITED PARTS WARRANTY ON KOBE BRILLIA SERIES:

For two years from the date of your original invoice from a KOBE authorized dealer, we will provide non-consumable replacement parts or components free of charge that failed due to manufacturing defects. Consumable parts such as light bulbs, filters, fuses, and oil cups are not covered by this warranty.

KOBE reserves the right to replace, rather than send out replacement parts of the product free of charge at our sole discretion.

WHAT IS COVERED:

This warranty is valid in the United States and Canada. It is non-transferable and applies only to the original purchaser and does not extend to any subsequent owners of this product. In Hawaii, Alaska, and Canada, this warranty is limited. There may be additional shipping charges for parts and service technician travel costs in remote areas or locations 30 miles outside of KOBE authorized service areas.

WHAT IS NOT COVERED:

- 1. Normal wear and tear, regular service and maintenance required for the product.
- 2. Consumable parts such as light bulbs, filters, fuses, and oil cups.
- 3. Chips, scratches, or dents due to abuse or misuse of the product, use of corrosive and abrasive cleaning products.
- 4. Damages caused by accident, fire, flood and other Acts of God.
- 5. Services in remote areas or locations 30 miles outside of KOBE authorized service area.
- 6. Labor cost incurred in connection with the removal of range hood, and installation of replacement range hood, nor does it cover any other contingent expenses.
- 7. Scratches inside the hood, back of the baffle filter, and inside the duct cover.

THIS WARRANTY WILL BE VOIDED BY:

- 1. Improper installation and failure to follow installation instructions.
- 2. Any repairs, alternation, modification not authorized by KOBE.
- 3. Duct alternation, modification, and connection.
- 4. Incorrect electric current, voltage, or wiring.
- 5. Improper usage of the product such as commercial, outdoor, or other usage other than residential indoor usage.
- 6. Purchasing this product from an unauthorized KOBE dealer.
- 7. Damaging the product due to negligence, misuse, abuse, or accident.

If we determine that the warranty exclusions listed above applies or if you fail to provide all necessary documentation for warranty service, you will be responsible for all expenses associated with the requested service, including parts, labor, shipping, traveling, and any other expense related to the service request.

TO REQUEST WARRANTY SERVICE, PLEASE CONTACT KOBE RANGE HOODS SERVICE CENTER:

From the 48 contiguous states:

Email (best): customer.service@koberangehoods.com

From Alaska, Hawaii, and Canada:

Email (best): customer.service@koberangehoods.com

WARRANTY INFORMATION FORM

Fills in the blanks and safe place for future se	keep this paper with the original invoice in a rvice purpose.
1. Date of purchase	:
2. Model No.	:
3. Serial No.	:
KOBE Service Center	or spare parts purchase in US, contact: service@koberangehoods.com
_	or spare parts purchase in Canada, contact: service@koberangehoods.com
Your Notes:	



www.koberangehoods.com

This KOBE hood is made for use in the USA and CANADA only. We do not recommend using this hood overseas as the power supply may not be compatible and may violate the electrical code of that country. Using a KOBE hood overseas is at your own risk and will void your warranty.

Cette hotte KOBE est fabriquée pour usage aux États-Unis et au Canada seulement. Il n'est pas recommandé d'utiliser cette hotte à l'étranger puisque l'alimentation électrique pourrait ne pas être compatible et enfreindre le code de l'électricité de ce pays. L'usage de la hotte KOBE à l'étranger est à votre propre risque et la garantie sera annulée.

Esta campana de extracción KOBE ha sido fabricada para ser utilizada únicamente en EE.UU. y CANADÁ. No recomendamos la utilización de esta campana en el extranjero debido a que la fuente de energía podría no ser compatible y podría violar el código eléctrico de dicho país. Utilizar una campana KOBE en el extranjero será a su propio riesgo y anulará la garantía.

VER. 250318

Information subject to change without notice.